

VRX Company<sup>Inc.</sup>

Application Note:

VIDEO SERVER E

Text Inserter Demo

**NOTICES**

This document is copyright by VRX Company Inc. Copyright law prohibits reproduction of any part of this document in any form without express written permission.

Notice: The contents of this document are subject to change without notice. At VRX Company Inc., we have made ever effort to ensure the accuracy of the contents of this document. However, we reserve the right to change this document for improvements without notice. If you find errors, please bring them to our attention. Our contact information is located at the bottom of this page.

**Table of Contents**

[Abbreviations and Phrases.....](#) [2](#)

[VRXSALES Demo Web Site.....](#) [3](#)

[Log in to Download the AP.....](#) [3](#)

[Start Video Server E.....](#) [3](#)

[Other Items to Check.....](#) [4](#)

[Special Demonstrations.....](#) [4](#)

[Contact Us.....](#) [4](#)

**Abbreviations and Phrases**

DVR	Digital Video Recorder
IP	Internet Protocol
VRX	Video Record Xperts

**Table 1** Abbreviations used in this manual

**Objective and Scope**

The objective of this document is to show how view demonstrations of VRX Company Text Inserters over the internet.



Contacting the VRX Company Inc.  
Send email to: support@vrxinc.com.

## VRXSALES Demo Web Site

The VRX Company web site uses an inexpensive DVR, which you can monitor over our internet connection. As of June 2008, we are using a dynamic IP address provided by Dynamic Network Services Inc. (DNS Inc.) For more information on dynamic IP addresses, visit them at: <http://www.dyndns.com/>

### Log in to Download the AP.

You will need to download and install software to view the video server. Begin the process by at our demo web site.

The VRX Company server IP address is

<http://vrxsales.homeip.net:8080/>

You will come to a log in screen.

Enter Username "visitor " and Password is "visitor"

On some systems, the demo video may become immediately available.

If not you need to down load the AP. Select the link circled in red as shown in the image at right.

Save the download file to a temporary folder.

When the down load completes run the file to install the program **Video Server E**. The file is quite large and the down load may take several minuets.



### Start Video Server E



Double click the Video Server E icon (pictured at left) to start the viewer.

The log in window will appear (pictured at right.)

1. Change the user name (to the right of the image of the person wearing a red tie) to "visitor".
2. Change the password (to the right of the image of the pad lock) to "visitor".
3. Change the IP address to "vrxsales.homeip.net"
4. Set the port to **8080** if necessary.
5. Press the green arrow image to complete the login.



.You should now have an image on the Video Web Server monitor.

Contacting the VRX Company Inc.  
Send email to: [support@vrxinc.com](mailto:support@vrxinc.com).



As a **visitor**, your privileges are limited to viewing only the camera we have chosen. You are not able to change any of the settings on the viewer for the Video Web Server.

## Other Items to Check

If you cannot see the demo at this point, you may need to download and install JAVA on your computer. Although we have not had to install JAVA for any of our computers we assume from the presence of the Download JAVA button on the log in screen that some computers will require such a download.

## Special Demonstrations

If you have data from a point of sale system, electronic scale or some other device you would like to see inserted onto video, please email to us a file. The file should be compressed so as to prevent changing or corruption of the file by email routers. Send the file to [support@vrxinc.com](mailto:support@vrxinc.com) with information about the file and your contact information including return email address, phone number, your name, your company name and a description of the file such as: Journal Printer SAM4s SPS1000 ECR.

You can find out how to capture data by referring to the VRX Company application note: [How To Capture Serial Port Data Using PC](#) on our web page.

## Contact Us

Please look for updated information on our web site at [www.vrxinc.com](http://www.vrxinc.com)

Contact the VRX Company Inc at [support@vrxinc.com](mailto:support@vrxinc.com) or by calling 1-866-543-8398 9-5 Eastern Time.  
Snail Mail at: VRX Company Inc. PO Box 4663, Maryville, TN 37802-4663

Contacting the VRX Company Inc.  
Send email to: [support@vrxinc.com](mailto:support@vrxinc.com).